

LUCOLINE INSTALLATION

1. Layout:




Use a building layout drawing with all lengths of the sides where Lucoline®should be installed to calculate the number of standard lengths, corners, cables and power supplies needed.

2. Prepare installation:




Use a laser line to mark the horizontal line on the building where the mounting clips should be installed. Per section install one Fixed Clip (L-CLIP-F) in the middle of the section to prevent it from moving on the building under temperature influences. Use Sliding Clips (L-CLIP-S) at a maximum repeat distance of 400 mm apart.

3. Types of mounting clips:




The Fixed Clip (L-CLIP-F) has rubber bands to prevent the tube from sliding. Only one should be used per section on a horizontal installation. In the case of a vertical installation use a Fixed Clip for every other clip to prevent the tube from sliding down under its own weight.

4. Install Lucoline® on clips:




Hang the tube in the top side of all clips. Push the tube downward to snap it into the spring part of each clip. Check that the tube is secured in all clips, especially the Fixed Clip.

5. Installation tube on clips:




6. Distance between sections:



To allow for thermal expansion and contraction and to prevent damage the individual sections need to have a gap between them. Later covered with a joint cover.


When installing at an ambient temperature above 10 $^{\circ}$ C leave a minimum gap of 15 mm between sections. Below 10 $^{\circ}$ C this can be 10 mm.


7. Corners:




To install a corner on 2 sections these should overlap each other so that the end of the section is flush with the top of the other section. Again leave a gap as in the drawing to allow for thermal expansion. Snap the corner over the 2 sections to fix it.

8. JST Connectors:










The JST connectors have a locking clip. Make sure these are fully engaged, making the connection IP67 water proof. Hide the connectors behind the tubes once connected. Do not pull or bend the cables too tight. This may damage the seal and compromise the IP rating.


To close off all open connectors in an installation and make them waterproof male or female blanking connectors must be used. Otherwise water can get into the open connectors which will lead to failures.

9. Installation of corners:










CUTTING



1. Cutting of the tubes: Locate the cutting positions (black dots) at the back of the tubes placed at every 55mm apart. Align the cutting position with the middle of the saw blade, place the tube flat on the platform, and cut the tube perpendicular to the saw blade. Please make sure that the saw blade is sharp to ensure that the cutting end face is smooth.

2. Clean inside tube from plastic and aluminium residue.

3. Sand the edge: Sand the edge of the tube & the PCB with the fine sand paper to ensure the edge is smoothened & uniform. Push back the PCB inside the tube.

4. Fix end cap: Fill the edge of the cap with PMMA glue (Weldon 16, Acryfix or similar). Push it on the tube and hold for 30 seconds.

5. Fix a tape to cure: Put a piece of masking tape over the end cap and tube and let it cure for at least 20 minutes before handling it.

POWER SUPPLIES AND CAPACITY

Specification 24V Power Supply

Code	Output Current	Output Power	Input Current	Efficiency	Size	Weight
PP2460	2.5A	60W	0.65A/115V-0.35A/230V	≥ 87%	184x44x34mm	0.52kg
PP24100	4.16A	100W	1.1A/115V-0.55A/230V	≥ 92%	204x67x35mm	0.88kg
PP24150	6.25A	150W	1.6A/115V-0.8A/230V	≥ 93%	234x68x35mm	1kg
PP24200	8.34A	200W	2.8A max	≥ 90%	295x60x36mm	1.1kg

Power Supply Capacity

Item	PP2460	PP24100	PP24150	PP24200
Power Output	60W	100W	150W	200W
All Lucoline® colours(5.0W/m)	11m	18m	27m	38m
RGB & RGB dot control	9m	15m	23m	31m

Maximum 4 sections of 2370mm | 9.6 m length in series

ELECTRIC LAYOUT EXAMPLE

